

Remove dirt with light force

Handy Cleaning Brush For Entrance & Balcony

Introduction

Handy brush for easily removing dirt on a floor with light force.



Easy-to-hold shaped grips

The rounded, easy-to-grip shape of the grip efficiently transmits power, allowing for light force to remove dirt.



Shaped brushes reach corners, edges, and grooves

The angled tip makes it easy to get into corners, edges, and grooves, and to remove dirt in places that are difficult to remove with a regular square brush.



Brush that gets into fine grooves and scrapes out dirt

Scraping brushes firmly penetrate fine grooves in concrete, tiles, exterior walls, etc., to remove dirt.




Brushes are replaceable for economical use

Replacement brushes (CVB04) are available so that brushes can be used longer and more economically.



Polyethylene is used for clean use because it does not absorb water

The use of polyethylene, which does not absorb water, allows for clean use.





Self-supporting and hanging for easy storage

It can be stored freestanding or suspended, and can be drained well and stored hygienically.



Four-layer construction of floor handy cleaning brush

The use of hard polyethylene between the bristles allows for efficient force transmission to the brush surface.

In addition, the material does not absorb water, so it can be used hygienically.

The stiff bristles get into the grooves of balcony and entrance floors to remove dirt.